



# Voltex Fitment Tow Hook Install Notes

## Honda S2000 2000-2009

---

### Install Notes:

1. Remove front bumper cover.
2. Arrange the threaded mounting plate inside of the box frame as pictured below.



3. The tow hook can be arranged one of two ways on either side. To have the tow hook come out through the main duct, arrange the spacer so that it is between the tow hook and the box frame.



4. To have the tow hook come out through the slot vent, mount the tow hook directly against the box frame.



5. Torque the supplied bolts to 30 ft-lbs.
6. Reinstall front bumper cover.



**Thank you for your order!**  
**Tag us on Instagram!**  
**@EVSTuning | #evstuning**